



Colourtrend Paints
(Aust) Pty Ltd
ABN 50 057 442 323
481 Victoria Street
Wetherill Park NSW 2164
Tel (02) 9756 2400
Fax (02) 9756 2405
331-04114

*RECOAT IN
ONE HOUR

interior / exterior PerfectPrep™

PURE ACRYLIC - PRIMER - UNDERCOAT - SEALER



CLEAN UP
WITH WATER



**PERFECT AS A
PRIMER FOR**
INTERIOR TIMBER
EXTERIOR TIMBER
TANNIN RICH TIMBER
PLYWOOD
TREATED PINE
GALVANISED STEEL
ZINCALUME
ALUMINIUM

**PERFECT AS AN
UNDERCOAT FOR**
BRICK
PVC PIPING
VINYL SLIDING
ALUMINIUM SIDING
PREVIOUSLY PAINTED
SURFACES
WOOD PANELLING
CERAMIC TILES
LAMINATES

**PERFECT AS A
SEALER FOR**
GYPROCK
MDF
FIBRE-CEMENT
HARDI-PLANK
MASONITE
PARTICLE BOARDS
CEMENT RENDER
MASONRY

**•12 YEAR•
GUARANTEED
NOT TO CRACK PEEL OR BLISTER***

"Guaranteed not to crack, peel or blister when applied according to the label directions for the appropriate surface. Colourtrend Paints (Aust) Pty Ltd will provide free of charge, sufficient paint to recoat areas affected by any failure to perform. The remedy is limited to free re-supply of the paint only. The guarantee does not cover failure due to the nature or any breakdown of previous coatings."

NOTE: Apply Perfect Prep on to a small section of the substrate and allow to dry for 48 hours. Complete soundness test to evaluate suitability of adhesion of this product to the substrate prior to application.

Product Summary
Use: Interior / Exterior
Application: Brush, roller or spray
Drying Time on a day of around 25°C
Touch Dry: 30 minutes
***Recoat:** 1 Hour@50% relative humidity
Clean Up: Water
Coverage: Up to 16 sq metres per litre depending on porosity of substrate

Directions Prepainted Surfaces

- Ensure surface to be painted is sound. (see Soundness*)

- Remove all traces of dirt, grease, oil, smoke deposits and any other contaminants.

- Remove all flaking, peeling material.

- Fill all imperfections with appropriate filler.

- Spot bare/repaired area with Australis PerfectPrep prior to applying full coat.

- Dust down and apply one coat of Australis PerfectPrep followed by finished coat/s.

- Sand all greying timber and apply one coat of Australis PerfectPrep followed by finished coat/s.

New Timber

- Interior/Exterior: Fill all imperfections with appropriate filler, sand, dust down and apply one coat of Australis PerfectPrep followed by finished coat/s.

- Sand all dressed timber.

Brick, Masonry, Cement Render and Fibre Cement

- Ensure surface to be painted is free from all contaminants, including mould, moss, lichen, efflorescence etc. Dust off and apply one coat of Australis PerfectPrep followed by finished coat/s.

- Cement Render must be allowed to cure for 28 days prior to application of Australis PerfectPrep and subsequent finish coat/s.

Galvanised Steel, Zincalume, Aluminium (Corrosion Free):

- Ensure surface to be painted is free from contaminants, including dirt, grease, oil etc.

- New Galvanised Steel and Zincalume may be left to weather prior to painting, if to be painted immediately, they should be thoroughly degreased using non metallic scourers and Mineral Turps. Surface should be thoroughly washed down with detergent solution followed by clean water.

- Apply one coat of Australis PerfectPrep followed by finished coat/s.

Vinyl and Aluminium Sidings

- Ensure surface to be painted is free from contaminants, including dirt, grease, oil etc. Chalking material should be thoroughly removed with non metallic scourers and detergent solution, followed by clean water. Care should be exercised so as not to score existing coating by harsh scouring.

- Apply one coat Australis PerfectPrep followed by finished coat/s.

Ceramic Tiles, Laminates, Gloss Enamel

- Ensure surface to be painted is free from contaminants, including dirt, grease, oil and soap scum. Apply one coat of Australis PerfectPrep followed by finished coat/s. PerfectPrep is not intended for use in areas subject to water flows and/or steam as in shower recesses etc.



interior / exterior
PerfectPrep™

PURE ACRYLIC - PRIMER - UNDERCOAT - SEALER

Soundness*

- To determine the soundness of the surface to be painted, cut a small cross in the paint film with a sharp instrument, firmly apply a piece of tape and sharply remove. Any evidence of the paint film adhering to the tape is indicative of an unsound surface. This process should be carried out at several locations to test the entire surface.

Application

- **Important** - Check weather forecasts and do not paint where forecasts indicate that rain is imminent, the temperature is likely to fall below 10°C or relative humidity will exceed 80%.

- Stir well prior to use and occasionally during use.

- During hot weather, painting should be commenced in an area away from direct sunlight. The addition of 50ml of water per litre will assist application in hot, dry conditions.

- Use sparingly on contact surfaces. The application of a second coat of Australis PerfectPrep will assist in evening out varying surface textures.

Safety

Keep out of reach of children. Avoid contact with skin and eyes. Avoid inhalation of vapour by providing adequate ventilation.

First Aid

Eyes: Rinse with running water for at least 15 minutes. If irritation continues seek medical advice.

Swallow: Drink plenty of water and immediately seek medical assistance.

Inhaled: If area contaminated by vapours, seek medical assistance if effects continue.

Disposal

- When cleaning up after painting, ensure that paint does not get into gutters or drains as it may contaminate waterways. For a free brochure on cleaning up after painting and the disposal of surplus paint, ring 1800-8-07558 (free call).

Do not reuse empty cans. This can is recyclable. Check with your local council to see if it is participating in a steel can recycling programme.

*The benefits conferred by this guarantee are in addition to all other rights and remedies in respect of the product which the consumer has under the Trade Practices Act & similar State & Territory laws. Any limitation herein, or any remedy available to a consumer shall not be to the extent of, or in conflict with, such statute such statute shall be severable.